

Television Servicing 12 CD

Files in pdf format, includes schematics and adjustments etc.

Makes & Models Covered

11 AK CHASSIS

11 AK 30-A2
11 AK 30-A5
11 AK 30-A6
11 AK 30-A8
11 AK 30-J
11 AK 36-A2
11 AK 36-E4
11 AK 41 (i)
11 AK 44 (i)
11 AK 49

BEKO

12.3 Chassis
20.2 Chassis
PA Chassis
PE-5 Chassis

BUSH

CTV 3418 BLK
RP 40 TV
RP 43 TV
RP 51 TV

DAEWOO

CP 099 F
CP 425 G
CP 485 F
CP 822 F
DDT 14 H9 S
DDT 21 H9 ZZ
DDT 21 H9 S
DDT 21 H9 ZZR
DP 32 SM/SP
DP 42 GM/GP
DP 42 SM/SP
DP 42 WM/WP
DSC 3210 E
DSC 3220 E/L
DSC 32W9 UZF-S
DTA 3220 ZZ
DTA 3220 ZL
DTA 32 W9 ZL
DTA 32 W9 ZZ
DTB 21 U7 (i)
DTF 29 U8 (i)
DTP 25 (i)
DTP 28 A7 (i)
DTP 28 G7 (i)
DTP 28 G8 (i)
DTP 28 B1 (i)
DTP 29 (i)
DWF 28 W8 GB (i)
DWL 28 W9
SC 140
SC 150
SP 115

FERGUSON

FTV 28 FW2
FTV 32 FW2

FORMENTI

PC 220 (Swing)

GOLDSTAR/LG

MC 036A Chassis
MF 002A Chassis
ML 012C Chassis
ML 024F Chassis
ML 027A Chassis
ML 041A Chassis

GOLDSTAR/LG Cont'd

RE 20 LA30
RE 32 FZ30 RQ
RL 32 FZ30 RQ
RZ 20 LA60
RZ 29 FB51 RQ/RX
RZ 17 LZ10
RZ 17 LZ40
RZ 20 LA60
RZ 26 LZ50

GOODMANS

1495 TIB
1790 T
TW 28 D11 (i)
TW 32 D11

GRUNDIG

28 WF 100
32 WF 100
TVR 3735 / 1 TOP
TVR 3735 / 2 TOP
TVR 3740 FR / TOP
TVR 3740 FT / GB
TVR 3740 / 1 TOP
TVR 3740 / 2 TOP
TVR 5540 FR / TOP
TVR 5540 FT / GB
TVR 5540 / 1 TOP
TVR 5540 / 2 TOP

HITACHI

A8/ D8 Chassis Mk II
C 32 WF 523 N-311
C 32 WF 727 N
C 32 WF810 N-311
C 36 WF 810 N-311
C 36 WF 830 N
CL 28 WF720 AN-300
CL 32 WF720 AN-300
CL 32 WF720 AND
CL 32 WF727 N
CL 32 WF810 AN-300
CL 36 WF810 AN-300
CL 36 WF830 AN
D36 WF840 N

JVC

AV 14BJ8 ENS
AV 14BJ8 EPS
AV 14BJ8 EES
AV 14BM8 ENS
AV 14BM8 EPS
AV 14BM8 EES
AV 21 ET G2
AV 2124 EE
AV 25 S4 EK
AV 25 SD4 EK
AV 28 EA8 SK
AV 28 SD4 EK
AV 29 BH11 EES (i)
AV 29 BH11 EPS (i)
AV 29 BH11 EES (i)
AV 29 J334/ V
AV 29 L31/ M
AV 32 WL1 EU
AV 32 WL1 EI
AV 32 WL1 EK
CG Chassis (ii)
CH Chassis
CW Chassis
FL Chassis

JVC Cont'd

LT 15 B60 SJ
LT 17 E31 BUG/ BJJ
LT 17 E31 SUG/ SJG
LT 17 E75 BJJ
LT 17 E75 SJG
LT 26 D50 BJ
LT 26 D50 SJ
MD Chassis

MATSUI

28M2

ORION

28 WDA
286 BE
286 DE
32 HDA
4155 ST
612 VT
740 VT
7400 TRC
8800 RC
C612 VT
T-2188 MJ
T-2190 MJ
T-2190 MTX
PCB TMC572B
Studio 631
Studio 709 (i)
Studio 710
Torus 730
Triade 3400
TV 28301
TV 715

PANASONIC

Euro 7 Chassis
Euro 7 VP Chassis
Euro 10 Chassis
LH 35 Chassis
TX 22 LX2 F/P
TX 28 DT 30
TX 28 PB 50
TX 28 PS1
TX 32 DT 30
TX 32 PB 50
TX 32 PB 50 N
TX 32 PS 1
TX 36 DT 35
TX 36 PB 50
TX 36 PB 50 N
TX 47 PT 10 F
TX 47 PT 10 F/ P

PROFESSIONAL (ORION)

Pro 4200 Chassis
Pro 4300 Chassis
Pro 4800 Chassis
Pro 8500 Chassis (Ver. D)

PROLINE

TVD 1430 (DVD Part)

QUADRO

CTV 1400
CTV 1401
CTV 1411
CTV 1415
CTV 1426
CTV 1433
TVG 141

ROADSTAR

CTV 1424 XT (i)
CTV 5501
CTV 5501 I
CTV 5509 KL
LCD 1512

SAMSUNG

CW 21 D83 NS
CW 533 CNG
CW 533 CNS
CW 533 CWG
CW 5344 NG
CZ 21 D83 NS
KS1A (P) Rev 1
KS3A Rev 2
PLT 51A Chassis
SP 403 JHAX

SANYO

25 BN1
C 25 EG64 NB
C 25 EG65 NB
CE 28 WN3 B
CE 28 WN3 C
CE 32 WN3 B
CE 32 WN3 C
EB4-A Chassis (i)
EB5-W Chassis

SHARP

21 LT 45 S ES
LC 15B2 EA
LC 20A2 M

SONY

AE 5 Chassis
BE 4 Chassis
BE 5 Chassis
KP 46 S4 U
KP 53 S4 U
KV 14 M1 U
KV 14 T1 U
KV 16 WS1 U
KV 20 WS1 U
KV 28 FC 60
KV 28 LS 60 U
KV 32 FC 60
KV 28 LS 60 U
RX-1E Chassis

TOSHIBA

15 V31 B
28 YT 56
32 YT 56

VESTEL

1451
17MB18-4
2285
2450

Models and chassis indicated by (i), (ii) or (iii) etc differ to previously published information.