

Television Servicing 13 CD

Files in pdf format, includes schematics and adjustments etc.

Makes & Models Covered

11 AK CHASSIS (Vestel)

11 AK 20 M6
11 AK 26-6

AIWA

TV F21 TS1 B
TV F21 TS1 E
TV F21 TS1 K
TV F21 TS1 U
VX D1420 K
VX F205 U
VX FT21 KL

BEKO

42 P6 B43 SIL
42 P6 L43
LC/ L5C Chassis
L5A Chassis
L6B Chassis

BUSH

ID LCD 27 TV006 (L6B)
ID LCD 27 TV22 HD (sch)
LCDS 20 TV00

DAEWOO

CP 185 F Chassis
CP 185 L Chassis
CP 521 F
DSJ 4710 CRA
DSJ 4720 CRA
DSJ 5510 CRA
DSJ 5520 CRA
DSP 4210 GM
DTB 21 U6
SJ 112 Chassis
SP 110 Chassis

GOODMANS (Bush)

GTV 147 (i)
GTV 34 R2
GTV 34 T2
GTV 42 P3/4

GRUNDIG

26 LW 68-7510 (Amira)

HITACHI

15 LD 2200
17 LD 4200
42 PD 3200 A
42 PD 4200
42 PD 6600
42 PD 6600 A
42 PD 7500 /A
C 24 W410 SN (Sch)
C 24 W430 N (Sch)
C 24 W511 TN (Sch)
C 28 W410 SN/TN (Sch)
C 28 W411 TN (Sch)
C 28 W430 N (Sch)
C 28 W433 N (Sch)
C 28 W510 SN/TN (Sch)
C 28 W511 NA (Sch)
C 32 W1 TN (Sch)
C 32 W433 N (Sch)
C 32 W510 SN (Sch)
C 32 W511 TN (Sch)
C 32 WD2 TN2 (Sch)
CL 28 W410 TAN (Sch)
CL 32 WD2 TAN2 (Sch)
CP 28W 410 TAN (Sch)
PW1 A Chassis
PW2 Chassis

JVC

LT 20B60 SJ/SU
LT-20DA6 SK
LT-26C31 BJE/BUE
LT-26C31 SJE/SUE
LT-26WX84 SJ
LT-30E45 SU (Sch)
MK Chassis
SB-5 Chassis

LG

15 LC1 RB-MG
20 LC1 RB-MG
32 LC2 D (U)
37 LC2 D
42 LC2 D
42 PX4 D
42 PX4 D-UB
42 PX4 R
42 PX4 R-ZA
AF-05B Chassis
CL 81 Chassis
LA63 E Chassis
MF 056A Chassis
ML 041A Chassis (i)
ML 051B Chassis
PDP 42 V6
RE 21 FB 50 RX
RT 37 LZ 55
RZ 30 LZ 50 (Parts Only)
RZ 37 LZ 55

LOGIK

LCX 27WN2
LCX W30NN6

MEDION

MD 30112

ORION

28 DDA
32 DDC
G14 DVD13
G14 DVD13 (i)
LT 7055 VT (Parts Only)
TVC 16997 (Parts Only)
PCB BMD004
PCB TM9423
PCB TMC572A
PCB TMC574
PCB TMC574 (i)
PCB TMX473A
PCB VMC316
PCB VMX177
PCB VMX199
TV 28 VPB
TV 2810 (Parts Only)
TV 28100
TV 28200
TV 325 DF (Parts Only)
TV 71100
TV 8210 (Parts Only)
TV 82200

PACIFIC

PTV 3606

PANASONIC

Euro 4 Chassis
Euro 4H Chassis
Euro 9S Chassis
GP9 DE Chassis
GPH5 D Chassis
LL 10 Chassis
TH 32 LHD7 UY

PANASONIC Cont'd

TH 32 LHD7 UXK
TH 32 LHD7 UXS
TH 32 LHD7 BK/BS/EK/ES
TH 37 PV60 B
TH 37 PW5
TH 37 PWD 5
TH 37 PX60 B
TH 42 PHD 5
TH 42 PHW 5
TH 42 PV60 B
TH 42 PW 5
TH 42 PWD 5
TH 42 PX60 B
TX 21 JT2
TX 25 SL1F
TX 28 SL1F
TX 29 AS10 C
TX 29 AS10 C/B
TX 29 PM1 D/F/P
TX 29 PX 20 D
TX 29 PX 20 F/P
ZM3L Chassis

PHILIPS

28 PW 9417

PROFESSIONAL (Orion)

Pro 8000 Chassis

ROADSTAR

CTV 1415 X
CTV 1433 X
LCD 2040
TVL 151 M/N
TVL 201 M/N

SAMSUNG

C15A Chassis
C18A (P) Chassis
DW 21 G6 VD2X/XET
DW 28 G6 VD2X/XEU
DW 21 G6 VD3X/XEC
DW 21 G6 VD3X/XEF
DW 21 G6 VD3X/XEU
DW 28 G6 VD3X/XEU
DW 28 G6 VD3X/XEC
K55A (P) Youngstar Rev. 1
S42 SD-YD05
S42 SD-YD06
TI 14 C5 DF2S
TI 20 C5 DF2S
UW 21J10 VD5 X
UW 28J10 VD5 X
VC1A(P) Chassis
VC1A(P) Rev.1 Chassis
WS 28 A116 T
WS 32 A116 T

SHARP

37 GQ 20 H
LC 20 B2 EA
LC 37 AD1 E
Squad Chassis

SONY

AE-4 Chassis
AE-6X Chassis
BE-3B Chassis
BX-1 Chassis
FE-2 Chassis (i)
KDL-20S200
KDL-20S2020
KF-50SX100 K/U

SONY Cont'd

KL-37W2 U (Rev.)
KL-40WA1 U
KP-44PX2 U
KV-28CL10 B/E
KV-X2100 B
KV-X2101 A/B/D/K
KV-X2102 L/U
KV-X2103 E
KV-X25K1 A/B/D/E (net)
KV-X25K1 K/R/U (net)
KV-X2500 B (net)
KV-X2501 A/B/D/K (net)
KV-X2502 L/U (net)
KV-X2503 E (net)
KV-X2900 B (net)
KV-X2901 A/B/D/K (net)
KV-X2902 L/U (net)
KV-X2903 E (net)
LE-1 Chassis
LE-1A Chassis
LE-2 Chassis
LE-3 Chassis
SE-1 Chassis

TECHWOOD

LCD 3211

TOSHIBA

14 VL 43 P
14 VL 44 B (L5A)
14 VL 44 B (L5C)
15 VL 63
17 WL 46 B/G
17 WL 56 B/G
17 WLD 46 B/G
17 WLT 46 B
17 WLT 56
20 VL 43 P
20 VL 44 B (L5A)
20 VL 44 B (L5C)
21 N21 B2
23 WL 46
27 WL 46 B
27 WLG 65
30 WL 46 B
VTD 1420
VTD 1431
VTV 1402 B/S

VESTEL

17MB08-3
17MB08P-3 (sch)
17MB11
17MB15-1
17MB15E-1
17MB15E-5
17MB16P-1
17MB17-2
17MB18-2
17MB18-5

WHARFEDALE

LCD 2010 AF

Please Note:
Models and chassis indicated by
(i) differ to previously published
information.

(Sch) Indicates Schematics Only