

Television Servicing 14 CD

Files in pdf format, includes schematics and adjustments etc.

Makes & Models Covered

11 AK CHASSIS

11 AK 45 B4

AIWA

TV 14MT11 K
TV SA 2155
VX G143 K Rev
VX T1470 PH

BEKO

12.6 Chassis
12.8 Chassis
14 B9 T46 S
14242-8TDS
16.1 Chassis
20242-8R
21 B9 T44 TXS
21 C2 TG1
22.1 Chassis
LCD 20 inch
PM 0314 XBS
PM 1121 XB

BLUE SKY

BK 55 PL

DAEWOO

CP 185 L/G Chassis
CP 185 M Chassis
CP 520
CP 520 A
CP 520 F
DTC 20 T2
DTC 21 Y1
DTC 21 Y2
DTY 21 B4
DTY 21 U7
DTY 25 G6
DTY 28 A7
DTY 28 A8
DTY 2880
DTZ 2481
DTZ 2881 GB
DTZ 29 U7

GOLDSTAR/LG

21 FS4 R LX
21 FS4 R LX-ZV
42 PX3 RV
42 PX3 RVB-ZA
42 PX5 D
42 PX5 D-EB
CW62B Chassis
DI 32 Q82
DF 054B Chassis
KE 14 P2 B
MF 056A Chassis (i)
MP 00MC Chassis
MT 42 PZ10
MV 995B Chassis
MZ 40 PA 10
MZ 42 PZ 10
MT 42 PZ 44/ S/ 45M
MZ 42 PZ 44/ S/ 45V
P 414 I
P 434 I
PD 00JA Chassis
RF 03 FA Chassis
RK 14 CC 40 M
RK 20 CC 40 M
RK 21 CC 40 MX
RT BA 50
RT 42 PZ 45V
RZ BA 50

GRUNDIG

P 37-1201/ 5 TOP
P 37-2201 (Davio)
P 37-2301
P 37-3201
P 37-4201 TOP
P 37-4201/ 5 TOP
T 51-1201/ 5 TOP
T 51-2401 TEXT (i)
T 51-4201/ 5 TOP
T 55-1201/ 5 TOP
T 55-4201 FR/ TOP

HITACHI

15 LD 3200
20 LD 3200
26 LD 6200
26 LD 6200 IT
28 LD 5200 E
32 LD 6200
PW1 L Chassis

JVC

AV 25 PS
AV 28 GT1 B/J
AV 28 GT1 S/J
AV 28 GT1 BU/F/A
AV 28 GT1 SU/F/A
AV 28 GT1 BU/F/B
AV 28 GT1 SU/F/B
AV 28 GT10 UF
AV 28 GT1 BU/F/C
AV 28 GT1 SU/F/C
AV 42 PD 20 ES
AV 56 WP30
FP2 Chassis
FT Chassis
FT Chassis (i)
HR XV3 EK
HR XV3 EX
HR XV31 EK
HR XV32 EK
HR XV31 EX
HR XVS30 EK
HR XVS30 EX
JK Chassis (ii)
LT 26 A60 BU
LT 26 A60 SJ
LT 26 A60 SU
LT 26 A61 BU
LT 26 A61 BU/ C
LT 26 A61 SJ
LT 26 A61 SU
LT 26 A61 SU/ C
LT 32 A61 B/J
LT 32 A61 BU
LT 32 A61 BU/ C
LT 32 A61 SJ
LT 32 A61 SU
LT 32 A61 SU/ C
LT 30 E45 SU (SM)
MF Chassis (ii)
MK Chassis (i)
PD 35 D30 ES
PD 50 X575
SB-2 Chassis

MATSUI

TVR 180 T

mitsubishi

HVS 451 B

ORION

PCB CME036
PCB TMB538
PCB VM8158
PCB VM9162

PANASONIC

Euro 4 Chassis (vi)
Euro 7 Chassis (i)
GLP 22 Chassis
GPF9 D Chassis
TH 50 PF9 UK
TX 15 AT1 L
TX 21 AP1
TX 25 CK1
TX 26 LMD 70
TX 26 LMD 70 F
TX 26 LMD 71 F
TX 28 CK1
TX 28 MK1
TX 32 LMD 70
TX 32 LMD 70 F
TX 32 LMD 71 F
TX 32 LMD 72 F
TX 36 PL 30
Z 8 Chassis (i)
Z 8T Chassis

PROFILO / TELRA

PT 92 J Chassis (Ver. G)

ROADSTAR

CTV 1434
CTV 2020 XT

SAMSUNG

C15A Chassis (i)
CW 29 M066 VGXXEC
CW 29 M066 TGXXEC
DVD 809
GBD 26 KE Chassis
GBR 26 KE Chassis
GBR 37 KE Chassis
GBD 40 KE Chassis
GLY26KE Chassis
GLY32KE Chassis
GLY37KE Chassis
GLY40KE Chassis
K55A (P) Youngstar Rev. 1 (i)
LE 23 R51 B
LE 26 R51 B
LE 26 R71 B
LE 26 R72 B
LE 26 R73 BD
LE 26 R74 BD
LE 26 R75 B
LE 32 R51 B
LE 32 R71 B
LE 32 R72 B
LE 32 R73 BD
LE 32 R74 BD
LE 32 R75 B
LE 32 R76 B
LE 37 R72 B
LE 37 R74 BD
LE 40 R51 B
LE 40 R71 B
LE 40 R72 B
LE 40 R73 BD
LE 40 R74 BD
LE 40 R75 B
LE 40 R76 B
S15 A Chassis (i)

SAMSUNG Cont'd

S42 SD-YB03
S62B (P) Shine
TW 14 C52S
WI 28W6VD
WI 28W6VN
WS 32 Z306 V

SANYO

CE 28 DN9-B
EB8-A28 Chassis

SHARP

LC 20 S1E
LC 20 SH1E
LC 30 AD1E
LC 32 GD9 EE
LC 32 GD9 F
LC 32 GD9 I
LC 32 GD9 K
LC 32 GD9 RU
LC 37 GD9 EE
LC 37 GD9 F
LC 37 GD9 I
LC 37 GD9 K
LC 37 GD9 RU

SONY

KD 28 DX 40 U
KD 28 DX 50 U
KD 32 DX 40 U
KD 32 DX 50 U
KD 32 NX 200 U
KD 36 NX 200 U
KDE P37 XS1
KDE P42 XS1
KDL L32 MRX1 D
KDL L42 MRX1 D
KE 42 M1
KE P42 M1
KP 44 PS2
KP 44 PS2 U
KP 51 PS2
MRX1 Chassis
RE 3W Chassis

THORN

VR 414 LVA

TOSHIBA

21 N21 B3
28 N13 D (i)
VTW 2887

VESTEL

17MB11 (i)
17MB18

WHARFEDALE

E9 Chassis (ii)

Please Note:
Models and chassis indicated by (i) differ to previously published information.

(Sch) Indicates Schematics Only